



AIR CONDITIONER

Please see the following operational guidelines to ensure optimal usage of the air conditioner:

Date: AUGUST 2023

Panel location: A touchscreen remote control is conveniently positioned on the wall adjacent to the entrance door of your room.


Turn on: Engage the touchscreen interface by selecting the power symbol () to initiate the air conditioning system.

Customisable Settings: Select mode (Heat, Fan, Cool, Dry, or Auto) to suit your requirements. To do so, use the Up (^) or Down (v) Arrow icons to navigate through the modes. Once the desired mode is displayed, make further adjustments on fan force, temperature by using the Right (>) or Left (<) arrow icons.



Each pressing of the ▼ or ▲ button cycles through the following operation modes.

Select the desired operation mode.



Important Notes;

- Please kindly be informed that it may take up to 15-30 minutes for the heating/cooling element to achieve its optimal temperature. During this interval, the remote screen will display the "standby" message.
- Please do not hesitate to seek our help if you require further assistance.