ABODE HOTELS CANBERRA PTY LTD ABN: 81 041 402 610

> TUGGERANONG 150 Anketell Street TUGGERANONG ACT 2900

PO Box 4519 KINGSTON ACT 2604 P 1300 1 ABODE (22633) W abodehotels.com.au



WASHING MACHINE & DRYER

Please see the following operational guidelines to ensure optimal usage of the washing machine and dryer.

Date: __AUGUST 2023_____



Choose your setting: To tailor the washing cycle to your preferences, use the available options. On the left-hand side you will find buttons corresponding to temperature, spin level and dry level. These buttons allow for precise adjustments based on your specific requirements.

Start the cycle: Once you have chosen the desired program by adjusting the settings, press the "Start/pause" button to initiate the machine's operation. The selected program will start.

End of cycle: Once complete the machine will read END.

Once finished please press the 'POWER OFF' position to turn the machine off.

Important notes

- Please only use the laundry liquids provided by the hotel during the washing cycle. This ensures optimal performance and prevents any undesired outcomes. Washing liquid is available at reception 24/07.
- Please do not hesitate to seek our help if you require further assistance.

ABODE HOTELS CANBERRA PTY LTD ABN: 81 041 402 610

> TUGGERANONG 150 Anketell Street TUGGERANONG ACT 2900

PO Box 4519 KINGSTON ACT 2604 **P** 1300 1 ABODE (22633) **W** abodehotels.com.au





Start the cycle: Turn the dial to fit in with the time and fabric choice.

End of cycle: The dryer will stop once the time is up on the dial.

Important notes

• Please do not hesitate to seek our help if you require further assistance.