



ABODE HOTELS CANBERRA PTY LTD
ABN: 81 041 402 610

1300 122 633
PO Box 4519, Kingston ACT 2604

ABODE GUNGALIN
(02) 6108 4911
Cnr Anthony Rolfe Avenue & Gribble Street, Gungahlin ACT 2912
reception.gung@abodehotels.com.au
abodehotels.com.au

AIR CONDITIONER



Please see the following operational guidelines to ensure optimal usage of the air conditioner:

Date: _____ **December 2023** _____

Panel location: A remote control is conveniently positioned on the wall of your room.

Please see the following operational guidelines to ensure optimal usage of the air conditioner.

1. Firstly, open the sliding cover (by sliding downward)
2. Press ON/OFF button.
3. Press Mode button until symbol appears in first column.

Each pressing of the  or  button cycles through the following operation modes.

Select the desired operation mode.



Customisable Settings: Select mode (Heat, Fan, Cool, Dry, or Auto) to suit your requirements. To do so, press the mode button. Arrow icons to navigate through the modes. Once the desired mode is displayed, make further adjustments on fan force. Select the required temperature by pressing up and down button.

Important Notes:

- Please kindly be informed that it may take up to 15-30 minutes for the heating/cooling element to achieve its optimal temperature. During this interval, the remote screen will display the "standby" message.
- Please do not hesitate to seek our help if you require further assistance.