



ABODE HOTELS CANBERRA PTY LTD
ABN: 81 041 402 610


1300 122 633
PO Box 4519, Kingston ACT 2604

ABODE GUNGAHLIN
(02) 6108 4911
Cnr Anthony Rolfe Avenue & Gribble Street, Gungahlin ACT 2912
reception.gung@abodehotels.com.au
abodehotels.com.au

WASHING MACHINE AND DRYER COMBO

Please see the following operational guidelines to ensure optimal usage of the washing machine and dryer combo:

Date: _____ December 2023 _____



Choose your setting: To tailor the washing cycle, use the option 3 above temperature button. Below the temperature button you will find the drying option. These buttons allow for precise adjustments based on your specific requirements.

Start the cycle: Once you have chosen the desired program by adjusting the settings, press the "Start" button to initiate the machine's operation. The selected program will start.

End of cycle: Once complete the machine will read END.

You can now safely open the machine's door to retrieve your laundered items. As a precaution, please wait for a brief interval as the door mechanism releases gradually. Please do not force the door open, as certain washing or drying conditions might delay opening.

Once finished please turn the program dial to the 'OFF' position to turn the machine off.

Important notes:

- Please only use the laundry liquids provided by the hotel during the washing cycle. This ensures optimal performance and prevents any undesired outcomes. Washing liquid is available opposite of reception desk on amenities cabinet 24/07.
- Please Do Not exert force to open the door. Variations in temperature and water utilization might occasionally lead to a slight delay in door release.
- Please do not hesitate to seek our help if you require further assistance.