




MICROWAVE

Please see the following operational guidelines to ensure optimal usage of the microwave:

Date: June 2024

Control Panel





Quick Start

Use this feature to automatically programme the oven to cook food at 100% power.

- 1 Turn **Selector dial** left to set cooking time on the **Display screen**, then press **Start/+30Sec./Confirm** to start cooking.
- 2 Press **Start/+30Sec./Confirm** to start the cooking time. Additional presses of **Start/+30Sec./Confirm** will increase the cooking time by 30 seconds up to a maximum of 95 minutes.

Microwave cooking

- 1 Press **Microwave** and the LED will display 'P100'.
- 2 Press **Microwave** repeatedly to adjust the power level between 100% and 10%, or turn **Selector dial** to choose the power you prefer. The display screen will show 'P100', 'P80', 'P50', 'P30' or 'P10' for each additional press.
- 3 Press **Start/+30Sec./Confirm** to confirm your selection.
- 4 Turn **Selector dial** to set cooking time from 0:05 to 95:00 minutes.
- 5 Press **Start/+30Sec./Confirm** again to start cooking.

PRESS	DISPLAY	POWER LEVEL	DESCRIPTION
Once	P100	100%	High
Twice	P80	80%	Medium High
3 times	P50	50%	Medium
4 times	P30	30%	Medium Low
5 times	P10	10%	Low

Example: If you want to use 80% microwave power to cook for 20 minutes:

- Press **Microwave** once, the screen display 'P100'.
- Press **Microwave** again or turn **Selector dial** to choose 80% microwave power.
- Press **Start/+30Sec./Confirm** to confirm, and the screen will display 'P80'.
- Turn **Selector dial** to adjust the cooking time until the oven displays '20:00'.
- Press **Start/+30Sec./Confirm** to start cooking.

Note: The cooking time will increase/decrease in set increments as per below:

0-1 min	: 5 seconds
1-5 min	: 10 seconds
5-10 min	: 30 seconds
10-30 min	: 1 minute
30-95 min	: 5 minutes